

Safety Information and Operating Instructions

Drinking Water Bowser (DWI Approved)

1.0 General Information

ONLY TO BE USED BY A TRAINED COMPETENT PERSON

The main purpose of the bowser is to store fresh and clean water for drinking. The tank is elliptical in section, it is moulded from PLP 330/A602 Blue Polyethylene.

| Drinking | Length | Width | Height | Gross | Unladen | Pump | Hose size |
|----------|--------|-------|--------|--------|---------|--------|-----------|
| Water | (mm) | (mm) | (mm) | Weight | Weight | Fitted | Fitted |
| Bowsers | | | | (kg) | (kg) | | (mm) |
| 250 | 2750 | 1500 | 1220 | 1400 | 260 | Patay | RPVC1 |
| Gallons | | | | | | DD | 25 (ID)X |
| (1125 | | | | | | 70 | 31 (OD) |
| Litre) | | | | | | | |
| 500 | 3581 | 1879 | 1854 | 2900 | 600 | Patay | HDPVC1 |
| Gallons | | | | | | DD | 25 (ID)X |
| (2550 | | | | | | 70 | 33 (OD) |
| Litre) | | | | | | | |

2.0 Safety Instructions

- 1. Only a qualified or competent person is authorised to operate the bowser.
- 2. The drinking water bowser is recommended to be used on a flat and stable surface.
- 3. <u>ALWAYS CHECK IF THERE IS NO LEAK OR DAMAGE</u> BEFORE USAGE.
- 4. <u>IN WARM WEATHER, THE WATER SHOULD BE CHANGED</u> AT LEAST ONCE A MONTH.
- 5. THE REPLACEMENT OF THE WATER DEPENDS ON THE COMSUPTION OF THE END USERS.

3.0 Operation Practice before Usage

- 1. Park the Drinking Water Bowser on as near as possible to a level surface.
- 2. Slacken off the securing clamp handle on the front support leg.
- 3. Lower the front support leg or telescopic jockey wheel.
- 4. Re-tightened the clamp securely.
- 5. Remove the pin from the towing vehicle.
- 6. Disconnect the bowser from the towing vehicle.
- 7. Slacken off the rear support leg clamp.
- 8. Lower the rear support leg (if fitted).
- 9. Re-tightened the clamp securely.

Important Note: DO NOT OPERATE WITHOUT LOWERING AND LOCKING SECURELY THE REAR SUPPORT LEGS (If fitted with)

4.0 Opening Instructions for the 250 Gallons (1125 Litre) Drinking Water Bowser

- 1. Open the top hinged lid cover.
- 2. Open the inner black lid by turning the cover anti-clockwise approximately 45 degrees and lift open gently.

5.0 Opening Instructions for the 500 Gallons (2550 Litre) Drinking Water Bowser

- 1. The 500 gallons contains one filling inlet and one air vent. The filling inlet is 3" (75 mm inlet).
- 2. Remove the filler and air vent cap and before filling with water.

6.0 Filling Instructions of the Drinking Water Bowser

- 1. Open all drain valves and taps to empty stored water.
- 2. Thoroughly flush out tank with clean fresh water.
- 3. Close all drains valves and taps.
- 4. Fill the tank with clean fresh water.

7.0 Maintenance of the Drinking Water Bowser

A competent person examines the drinking water bowser every six months. The whole equipment including taps and valves should be checked. The Drinking Water Bowser should not be modified or disassembled. If there is any concern, any defect or damage, please contact your nearest Marwood Group Ltd Depot.